

Unless otherwise stated, all balsa is to be attached to paper covering material via applying glue from a glue stick to the balsa and then pressing the pieces together. Whereas, balsa and the toothpick (i.e. rear rubber motor stop) is to be attached to balsa via a small amount of white glue such as Aleene's Quick Dry Tacky Glue.

Fold, crease, and bend up 90 degrees, 3 places (dashed lines)

Location for attaching the wing shim to the bottom of the wing after it has been made.

1/16" x 1/8" Balsa Stick

1/16" x 3/16" Balsa Stick, 2 places

Tape this tab to the table or build board prior to making the wing.

1/16" x 3/16" x 2" Balsa Stick, 7 places

1/8" x 3/8" x 12" Balsa Stick

MOTOR STICK

1/8" x 1/8" x 4" Balsa Stick

The Wing Support is to be glued to the Motor Stick in the position shown and flush with the top the Motor Stick using a glue stick.

COPY PAPER SQUIRREL*

FIRST FLIGHTS CLASS

*Adapted from the original design by Darcy Whyte and is being used with permission.

20101130

1/16" x 3/16" x 6" Balsa Stick

ELEVATOR

Location for applying white glue when attaching these to the Motor Stick

RUDDER

